

What is the Story on Microseepage?

Many people have heard of macroseepage, but few people have heard about microseepage or understand the microseepage mechanism.

As most of us know, the term **Macroseepage** refers to **visible oil and gas seeps**. Macroseeps are very localized areas containing large concentrations of hydrocarbons that are restricted to the termination of faults, fractures, and outcropping unconformities or carrier beds. These visible seeps have led to the discovery of many of the world's important oil and gas producing areas (Link, 1952; Macgregor, 1993), see **Figure 1**.

In **Microseepage**, hydrocarbon compounds pervade the overlying seal and migrate vertically through the stratigraphic sequence to the surface. The leakage is not massive, as with a breach of a structural closure. This process is distinct from the movement of hydrocarbons along breaching faults or fracture swarms (i.e. macroseepage), with its consequent surface expression of an oil or gas seep (Silliman, 2005).

Due to vapor pressure limitations, typically only volatile or semivolatile hydrocarbons are expected above the water table. The existence of microseepage is supported by a large body of empirical evidence (Price, 1986; Klusman, 1993; Klusman and Saeed, 1996; Matthews, 1996).

Research and field studies suggest that the dominant migration medium is **continuous-phase, buoyancy-driven gas flow** within carrier and reservoir rocks and capillary imbibition in the transition from sources and seals into carrier rocks.

The migration of hydrocarbon compounds is nearly vertical in direction, so that surface expressions of these compounds overlay the subsurface accumulations. In this manner, detection of thermal hydrocarbons provides a valuable exploration capability (Silliman, 2005). Surprisingly, migration rates are fairly dynamic, ranging from less than 1 meter per day to tens of meters per day (Arp, 1992; Abrams, 1992)

Why should I care about anything but macroseepage?

Macroseepage is important because it denotes the presence of a petroleum system and the biomarker data can address depositional environment, age, maturity, etc. However, macroseeps are not omnipresent. Microseep data provides additional information such as structural boundaries, faults, hydrocarbon movement, reservoir depletion affects, field sweet spots (i.e. areas of higher pressure, porosity, and net pay) and can identify several liquid signatures denoting multiple sources.

Since oil contains compounds out to ~C₄₅, why is microseepage only analyzed up to C₂₀?

While most microseepage analyses analyze only C₁ – C₅, Amplified Geochemical Imaging analyzes C₂ – C₂₀. The primary limiting factor for the C₂₀ monitoring is the volatility of the hydrocarbon compounds themselves. C₂₀ is the approximate limit beyond which hydrocarbon compounds no longer

partition into the gas phase, thus preventing their transport through the reservoir seal.

If traditional methods report a detection limit of parts per million (ppm) for microseepage, then how can AGI report a detection limit of parts per billion (ppb)?

The AGI sampler, see **Figure 2**, contains a specially engineered oleophilic (i.e. oil loving) adsorbent encased in a microporous membrane. These membrane pores are small enough to prevent soil particles and water from entering, but are large enough to allow hydrocarbon molecules to pass through. The result is an ultrasensitive technology that is approximately 1,000 times more sensitive than traditional methods.




Figure 1.




Figure 2.

